

## INSTRUCTIONS WHEN APPLYING FOR ABANDONMENT OF A WELL

**NOTE:** A well must be permanently abandoned or repaired if it acts as a source or channel of contamination. "abandon" means to discontinue the use of and to seal the well in accordance to the requirements of 15A NCAC 02C .0113.

### SITE PREPARATION

1. Property lines must be identified and should be flagged every 50 feet if they are within 100 feet of the existing well.
2. Well to be abandoned should be flagged.

**Once all the above are staked or flagged at your site, accurate measurements should be taken while on site for use on your site plan drawing.**

**Your site plan drawing should include the following.**

- Any prominent structures on the property (house, garage, barn, etc.)
- The well to be abandoned.
- The distance from the well to be abandoned to the closest prominent structure.
- The distance from the well to the nearest property line if within 100 feet of the well
- A directional arrow.

### EXAMPLE SITE PLAN DRAWING

